

3P Tuscan Butt

Art. No. 9000700K



6. Fitting the 3P Filter Collector

Push the green spiral hose on to the hosetail and secure with jubilee clip provided.

Fit the other end on to the smallest Filter Collector outlet.



Filter Collector Universal: Art. No: 2000840U



Locking the Lid

Rotate lid to lock and ensure child-safe.

3P Tuscan Butt

Art. No. 9000700K



3P Tuscan Butt 275 Litre

Installation Instructions

We recommend the optional 3P Filter Collector Universal to fill this water butt.

Where the water butt cannot be located within 30 cm of the down pipe, longer Universal Long Link Kits are available online (Art. No. 9000123U, U2, to U5).



You may also use other UK diverters. Refer to the instructions for your diverter.

If in any doubt during installation, please consult a professional tradesman.

3P Tuscan Butt

Art. No. 9000700K



Setting Up

Site the water butt on a firm level surface, adjacent to your down-pipe.

Refer to your down-pipe diverter instructions.

You can choose whether to fit the tap supplied, or not.

Fitting the tap (optional)



1. Locate Tap-point (Optional)

You do not have to install a tap. The Tuscan can be used by plunging a watering can into the water. To find the tap point: locate a flat, circular area on the side of the water-butt, around 300 mm from the bottom.



2. Hole cutter selection - 28 mm

Select the 28 mm flat bit from the set. This is the smallest available in the set. Please double check before drilling.



3. Drilling

Offer the drill to the centre of the tap point, mark if necessary. Carefully proceed to drill the hole with the 28 mm flat bit.



4. Attach tap and back-nut

Push the tap through the hole and screw the back-nut on tightly, this will form a watertight seal.

3P Tuscan Butt

Art. No. 9000700K

Attaching an optional 3P Filter Collector Universal



1. Marking Out

Measure down 70 mm from the lip of the water butt. This should be at a point well away from either of the two bayonet lid locking positions.

This position is ideal for all connections at 32 mm (DN32 , 1 1/4") or less.



2.1 Hole Cutter Selection - 32 mm

To fill the water butt with the recommended 3P Filter Collector Universal, select the 32 mm flat bit from the set provided.

2.2 Other Diverters & Connectors

Refer to your diverter's instructions for the correct sized hole to form. You *may* be able to use the flat bit supplied by 3P. Check your own diverter's instructions before proceeding.



3. Drilling

Offer the drill to the marked point, proceed to drill the hole at 32 mm (or at your selected holes size for your connection set). Check and re-check you are going to drill the correct size of hole for the connection set that you are using.



4. Attaching a Back-Nut & Hose Tail

A back nut and rubber seal can be fitted as shown. Hold the back-nut and rubber seal in position and screw in the hoesetail



5. Hoesetail in Position

This picture shows a 1" BSP thread - 32 mm hoesetail in position (within a 32 mm drilled hole).